
FPC-7600 Series

Robust Box PC with 3rd Generation Intel®
Core™ i5/i3 or Celeron® Processor Platform

User's Manual

Version 1.1



This page is intentionally left blank.

Revision History

Version	Release Time	Description
1.0	2015 August	Initial release
1.1	2015 October	Add FPC-7600 model

Revision History	i
Contents	ii
Preface.....	v
Copyright Notice.....	v
Declaration of Conformity.....	v
CE	v
FCC Class A.....	v
RoHS.....	vi
SVHC / REACH.....	vi
Important Safety Instructions	vii
Warning.....	viii
Replacing Lithium Battery	viii
Technical Support.....	viii
Warranty.....	ix
Chapter 1 - Introduction.....	1
1.1. The Computer	2
1.2. About this Manual.....	2
1.3. Specifications	3
1.4. Inside the Package.....	4
1.5. Ordering Information	5
1.5.1. Optional Accessories.....	5
1.5.2. Configure-to-Order Service	6
Chapter 2 - System Overview	7
2.1. Dimensions	8
2.1.1. FPC-7600.....	8
2.1.2. FPC-7601/7602/7603.....	9
2.1.3. FPC-7604.....	10
2.2. Take A Tour.....	11
2.2.1. Front Views	11
2.2.2. Rear Views.....	14
2.3. Driver Installation Notes	16
Chapter 3 - System Configuration	19
3.1. Board Layout.....	20
3.2. Jumpers and Connectors	22
3.2.1. Jumpers	22
3.2.2. Connectors.....	26
Chapter 4 - Installation and Maintenance.....	39
4.1. Install Hardware	40
4.1.1. Open the Computer.....	40
4.1.2. Install/uninstall Memory Modules	44

4.1.3. Install CPU	52
4.1.4. Install SATA Storage Devices.....	53
4.1.5. Install PCI and PCI Express Cards	56
4.1.6. Install Wireless Modules	58
4.2. Mount the Computer	59
4.3. Ground the Computer	60
4.4. Wire DC-in Power Source.....	61
Chapter 5 - BIOS	63
5.1. Main	66
5.2. Advanced	67
5.2.1. ACPI Settings.....	68
5.2.2. SS RTC Wake Settings.....	69
5.2.3. CPU Configuration	70
5.2.4. SATA Configuration.....	71
5.2.5. Intel(R) Anti-Theft Technology Configuration	72
5.2.6. USB Configuration	73
5.2.7. F81866 Super IO Configuration	74
5.2.8. F81866 H/W Monitor	76
5.2.9. Intel ICC	77
5.2.10. CPU PPM Configuration	78
5.3. Chipset.....	79
5.3.1. PCH-IO Configuration	80
5.3.2. System Agent (SA) Configuration	82
5.4. Boot.....	85
5.4.1. CSM Parameters.....	86
5.5. Security	88
5.6. Save & Exit.....	89
Appendices	91
A: Digital I/O Setting.....	92
B: Watchdog Timer (WDT) Setting.....	95
C: Wi-Fi Module WIFI-AT2300 Hardware Installation	96
C.1. Install WIFI-AT2300	96
D: Install Internal USB Drives.....	103

This page is intentionally left blank.

Copyright Notice

All Rights Reserved.

The information in this document is subject to change without prior notice in order to improve the reliability, design and function. It does not represent a commitment on the part of the manufacturer.

Under no circumstances will the manufacturer be liable for any direct, indirect, special, incidental, or consequential damages arising from the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Declaration of Conformity

CE

The CE symbol on the computer indicates that it is in compliance with the directives of the Union European (EU). A Certificate of Compliance is available by contacting Technical Support.

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from ARBOR. Please contact your local supplier for ordering information.

Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

FCC Class A

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Preface

NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

RoHS

ARBOR Technology Corp. certifies that all components in its products are in compliance and conform to the European Union's Restriction of Use of Hazardous Substances in Electrical and Electronic Equipment (RoHS) Directive 2002/95/EC.

The above mentioned directive was published on 2/13/2003. The main purpose of the directive is to prohibit the use of lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB), and polybrominated diphenyl ethers (PBDE) in electrical and electronic products. Member states of the EU are to enforce by 7/1/2006.

ARBOR Technology Corp. hereby states that the listed products do not contain unintentional additions of lead, mercury, hex chrome, PBB or PBDB that exceed a maximum concentration value of 0.1% by weight or for cadmium exceed 0.01% by weight, per homogenous material. Homogenous material is defined as a substance or mixture of substances with uniform composition (such as solders, resins, plating, etc.). Lead-free solder is used for all terminations (Sn(96-96.5%), Ag(3.0-3.5%) and Cu(0.5%)).

SVHC / REACH

To minimize the environmental impact and take more responsibility to the earth we live, Arbor hereby confirms all products comply with the restriction of SVHC (Substances of Very High Concern) in (EC) 1907/2006 (REACH --Registration, Evaluation, Authorization, and Restriction of Chemicals) regulated by the European Union.

All substances listed in SVHC < 0.1 % by weight (1000 ppm)

Important Safety Instructions

Read these safety instructions carefully

1. Read all cautions and warnings on the equipment.
2. Place this equipment on a reliable surface when installing. Dropping it or letting it fall may cause damage
3. Make sure the correct voltage is connected to the equipment.
4. For pluggable equipment, the socket outlet should be near the equipment and should be easily accessible.
5. Keep this equipment away from humidity.
6. The openings on the enclosure are for air convection and protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
7. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
8. Never pour any liquid into opening. This may cause fire or electrical shock.
9. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
10. If one of the following situations arises, get the equipment checked by service personnel:
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
 - e. The equipment has been dropped or damaged.
 - f. The equipment has obvious signs of breakage.
11. Keep this User's Manual for later reference.

Warning

The Box PC and its components contain very delicately Integrated Circuits (IC). To protect the Box PC and its components against damage caused by static electricity, you should always follow the precautions below when handling it:

1. Disconnect your Box PC from the power source when you want to work on the inside.
2. Use a grounded wrist strap when handling computer components.
3. Place components on a grounded antistatic pad or on the bag that came with the Box PC, whenever components are separated from the system.

Replacing Lithium Battery

Incorrect replacement of the lithium battery may lead to a risk of explosion.

The lithium battery must be replaced with an identical battery or a battery type recommended by the manufacturer.

Do not throw lithium batteries into the trash can. It must be disposed of in accordance with local regulations concerning special waste.

Technical Support

If you have any technical difficulties, please consult the user's manual first at:
<http://www.arbor.com.tw>

Please do not hesitate to call or e-mail our customer service when you still cannot find out the answer.

<http://www.arbor.com.tw>

E-mail:info@arbor.com.tw

Warranty

This product is warranted to be in good working order for a period of one year from the date of purchase. Should this product fail to be in good working order at any time during this period, we will, at our option, replace or repair it at no additional charge except as set forth in the following terms. This warranty does not apply to products damaged by misuse, modifications, accident or disaster.

Vendor assumes no liability for any damages, lost profits, lost savings or any other incidental or consequential damage resulting from the use, misuse of, or inability to use this product. Vendor will not be liable for any claim made by any other related party.

Vendors disclaim all other warranties, either expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose, with respect to the hardware, the accompanying product's manual(s) and written materials, and any accompanying hardware. This limited warranty gives you specific legal rights.

Return authorization must be obtained from the vendor before returned merchandise will be accepted. Authorization can be obtained by calling or faxing the vendor and requesting a Return Merchandise Authorization (RMA) number. Returned goods should always be accompanied by a clear problem description.

This page is intentionally left blank.

Chapter 1

Introduction

1.1. The Computer

- Fanless Design
- Wide Range DC Power Input (9~36V)
- Triple Independent display (DisplayPort x2 + VGA x 1) supported
- Two-mPCIe for Optional WiFi, GPS or I/O Expansion supported
- Optional WiFi or HSUPA Wireless Connectivity supported
- Rugged Design for Shock / Vibration Protection
- Memory Support up to 16GB (DDR3)



1.2. About this Manual

This manual is meant for the experienced users and integrators with hardware knowledge of personal computers. If you are not sure about the description herein, consult your vendor before further handling.

We recommend that you keep one copy of this manual for the quick reference for any necessary maintenance in the future. Thank you for choosing ARBOR products.

1.3. Specifications

System Kernel	
Processor	3 rd Generation Intel® Core™ i5/i3 or Celeron® Processors in rPGA988 socket, TDP under 35W
BIOS	AMI UEFI BIOS
Chipset	Intel® HM76
Graphics	Integrated Intel® HD 4000
System Memory	2 x 204-pin DDR3 SO-DIMM sockets, supporting 1333/1600MHz SDRAM up to 16GB
Serial ATA	2 x Serial ATA ports with 600MB/s HDD transfer rate
Ethernet Controller	2 x Intel® WGI210AT GbE controllers
Watchdog Timer	1 ~ 255 levels reset
I/O Ports	
Serial Port	COM1/ COM2 RS-232 COM3/COM4 RS-232/422/485 Selectable
*Selectable Port	1 x DB25 connector for 1 x digital I/O, 8-in/8-out or I/O Expansion (either one)
USB Port	2 x USB 2.0 ports, 4 x USB 3.0/ 2.0 ports Internal USB dongle (Optional)
LAN Port	2 x RJ-45 ports for GbE
Video Port	2 x Display ports 1 x DB-15 Female connector for Analog RGB
Audio	Mic-in/Line-out
Expansion Bus	2 x Mini-card for optional WiFi, GPS or I/O Expansion
Storage	
Type	2 x 2.5" drive bays
Qualification	
Certification	CE, FCC Class A
Environment	
Operating Temp.	-20 ~ 55°C (-4 ~ 131°F), ambience w/ air flow
Storage Temp.	-40 ~ 85°C (-40 ~ 185°F)
Operating Humidity	10 ~ 95% @ 55°C (non-condensing)

Introduction

Vibration	3 Grms/5 ~ 500Hz/random operation w/ SSD
Shock	Operating 40G (11ms); Non-operating 60G w/ SSD
Mechanical	
Construction	Aluminum alloy
Mounting	Wall mounting
Weight	4.0 kg (8.81 lb) for FPC-7600 4.9 kg (10.80 lb) for FPC-7601/7602/7603 4.5 kg (9.92 lb) for FPC-7604
Dimensions (W x D x H)	195 x 268 x 75 mm for FPC-7600 195 x 268 x 110 mm for FPC-7601/7602/7603 195 x 268 x 90 mm for FPC-7604
Power Requirement	
Power Input	DC 9~36V input w/ 4-pin terminal block
Power Consumption	Max.65W(w/o I/O Card)

1.4. Inside the Package

Upon opening the package, carefully inspect the contents. If any of the items is missing or appears damaged, contact your local dealer or distributor. The package should contain the following items:



FPC-7600



FPC-7601/7602/7603

OR



FPC-7604

1 x FPC-7600 Series
Robust System



1 x Driver CD
1 x User's Manual

1.5. Ordering Information

FPC-7600	Fanless system w/o expansion
FPC-7601	Fanless system w/ 1 x PCI and 1 x PCIe x16
FPC-7602	Fanless system w/ 1 x PCIe x8 and 1 x PCIe x16
FPC-7603	Fanless system w/ 2 x PCI
FPC-7604	Fanless system w/ 1 x PCIe x16

1.5.1. Optional Accessories

The following items are normally optional, but some vendors may include them as a standard package, or some vendors may not carry all the items.

PAC-B120W-FSP 19V/6.32A 120W AC/DC adapter kit



WMK-7000 Wall-mount kit for FPC-7XXX Series



Introduction

1.5.2. Configure-to-Order Service

Make the computer more tailored to your needs by selecting one or more components from the list below to be fabricated to the computer.

80GB SSD
Intel® 2.5" 80GB SATAIII SSD kit



WIFI-AT2300
Atheros AR9462 Wi-Fi module w/ 20cm internal wiring



ANT-D11
1 x Wi-Fi Dual-band 2.4G/5G antenna



3rd Generation Intel® Core™ i3-3120ME, L2/3M, 2.4G



3rd Generation Intel® Core™ i5-3610ME, L2/3M, 2.4G

MK-3C-4G-1
DDR3-1600 4GB SDRAM DIMM1 kit

MK-3C-4G-2
DDR3-1600 4GB SDRAM DIMM2 kit



MK-3C-8G-1
DDR3-1600 8GB SDRAM DIMM1 kit

MK-3C-8G-2
DDR3-1600 8GB SDRAM DIMM2 kit

UDK-7702
Internal USB dongle kit for FPC-7601/7602/7603




Chapter 2

System Overview


2.1. Dimensions

The following illustration shows the dimensions of each FPC-7601/7602/7603 and FPC-7604, with the measurements in width, depth, and height called out.

2.1.1. FPC-7600




2.1.2. FPC-7601/7602/7603



System Overview

2.1.3. FPC-7604




2.2. Take A Tour

The computer has some I/O ports and controls on the front and rear panels. The following illustrations show all the components called out for all FPC-7600 Series.

2.2.1. Front Views


- FPC-7600 Front



No.	Description
①	LAN ports
②	Antenna hole
③	Antenna hole
④	Power button
⑤	Reset toggle
⑥	USB 3.0 ports
⑦	USB 2.0 ports


System Overview

- FPC-7601/7602/7603 Front



No.	Description
①	LAN ports
②	Antenna hole
③	Antenna hole
④	Power button
⑤	Reset toggle
⑥	USB 3.0 ports
⑦	USB 2.0 ports

- FPC-7604 Front




No.	Description
①	LAN ports
②	Antenna hole
③	Antenna hole
④	Power button
⑤	Reset toggle
⑥	USB 3.0 ports
⑦	USB 2.0 ports

System Overview


2.2.2. Rear Views

Take a look at the rear sides of FPC-7600 Series.


- FPC-7600 Rear



- FPC-7601/7602/7603 Rear



- FPC-7604 Rear



2.3. Driver Installation Notes

The FPC-7600 Series support the operating systems of Windows 7, Windows 8 and Linux. For Windows O.S., find the necessary device drivers on the CD that comes with your purchase. For different O.S., the installation of drivers/utilities may vary slightly, but generally they are similar.

To install AHCI driver, the system's SATA configuration needs to change to AHCI first. See [5.2.4. SATA Configuration](#) on page [71](#) to know how to change the setting.

This computer supports Intel® Management Engine, a microcontroller embedded in the PCH chipset, which joins the associated firmware to form the architecture of Intel® AMT (Active Management Technology) for a remote management console to connect to a client through the network. Intel® Management Engine is able to work even in the absence of the O.S. (the “out-of-band” capability) To make Intel® ME work correctly on the computer, install the driver included on the CD.

Paths to find various drivers on the CD:

Windows 7

Driver	Path
Chipset	\\Chipset\Windows\10.0.13\SetupChipset.exe
USB 3.0	\\USB3.0\Setup.exe
VGA	32Bit \\Graphic\WIN7_32bit_V_36_15_0_1073\Setup.exe
	64Bit \\Graphic\WIN7_64bit_V_37_15_0_1073\Setup.exe
LAN	32Bit \\Ethernet\Win7-32bit\PROWin32.exe
	64Bit \\Ethernet\Win7-64bit\PROWinx64.exe
Audio	\\AUDIO\win7_win8_win10_r279.exe

Windows 8

Driver	Path	
Chipset	\\Chipset\Windows\v10.0.13\SetupChipset.exe	
USB 3.0	\\USB3.0\Setup.exe	
VGA	32Bit	\\Graphic\WIN8_8.1_32bit_V15.33.22.3621\Setup.exe
	64Bit	\\Graphic\WIN8_8.1_64bit_V15.33.22.64.3621\Setup.exe
LAN	32Bit	\\Ethernet\Win8-32bit\PROWin32.exe
	64Bit	\\Ethernet\Win8-64bit\PROWinx64.exe
Audio	\\AUDIO\win7_win8_win10_r279.exe	

This page is intentionally left blank.


Chapter 3

System Configuration


3.1. Board Layout

The main board FMB-i76M1 forms the engine of the FPC-7600 Series computers. This section will provide an thorough view of this board.

FMB-i76M1: Board Top



FMB-i76M1: Board Bottom



3.2. Jumpers and Connectors

The main board FMB-i76M1 comes with some connectors to join cables to other devices and some jumpers and DIP switches to alter hardware configuration. The following in this chapter will explicate each of the components one-by-one.



3.2.1. Jumpers

JBAT1


Function: CMOS Setting

Jumper Type: Onboard 2.54mm pitch
1x3-pin header

Setting:

Pin	Function	Setting
1-2	Keeps CMOS (Default)	
2-3	Clears CMOS	







Board Top




JME1

Function: BIOS Programing
MODE Selection
Jumper Type: Onboard 2.00mm
pitch 1x3-pin header

Setting:



Pin	Description	Setting
1-2	BIOS Programing Disable	1 
		2 
		3 
2-3	BIOS Programing Enable (default)	1 
		2 
		3 




J1

Function: AT/ATX MODE Selection
Jumper Type: Onboard 2.00mm pitch 1x3-pin header

Setting:

Pin	Description	Setting
1-2	AT	
2-3	ATX (default)	

Board Top




JTERM1

Description: COM3 RS422 & RS485 Terminator Selector

Jumper Type: Onboard 2.00mm pitch 2x3-pin header

Pin	Description
1-3	RS-485 Normal Mode
3-5	RS-485 120 ohm Terminal Mode
1-3, 2-4	RS-422 Normal Mode (default)
3-5, 4-6	RS-422 120 ohm Terminal Mode




JTERM2

Description: COM4 RS422 & RS485 Terminator Selector

Jumper Type: Onboard 2.00mm pitch 2x3-pin header

Pin	Description
1-3	RS-485 Normal Mode
3-5	RS-485 120 ohm Terminal Mode
1-3, 2-4	RS-422 Normal Mode (default)
3-5, 4-6	RS-422 120 ohm Terminal Mode




3.2.2. Connectors

SATA1 & SATA2


Description: Serial ATA connectors for storage devices

Connector Type: 7-pin Serial ATA connector

Pin	Description
1	GND
2	TX+
3	TX-
4	GND
5	RX-
6	RX+
7	GND



Board Bottom




PWR1 and PWR2


Description: Power connectors for SATA storage devices

Connector Type: 2.54mm-pitch 1x4-pin DIP-type connector

Pin	Desc.
1	+5V
2	GND
3	GND
4	+12V



Board Bottom




Engine of the Computer


MC1

Description: PCI Express MiniCard socket
Connector Type: Onboard 0.8mm pitch 52-pin edge card connector

Pin	Desc.	Pin	Desc.	Pin	Desc.
1	Wake	20	W_Disable#	36	USB D-
2	+3.3V	21	GND	37	GND
3	COEX1	22	PERST#	38	USB D+
4	GND	23	PERn0	39	+3.3V
5	COEX2	24	+3.3V	40	GND
6	+1.5V	25	PERp0	41	+3.3V
7	CLKREQ#	26	GND	42	LED WWAN#
8	UIM_PWR	27	GND	43	GND
9	GND	28	+1.5V	44	LED_WLAN#
10	UIM_DATA	29	GND	45	Reserved
11	REFCLK-	30	SMB_CLK	46	LED_WPAN#
12	UIM_CLK	31	PETn0	47	Reserved
13	REFCLK+	32	SMB_DATA	48	+1.5V
14	UIM_RESET	33	PETp0	49	Reserved
15	GND	34	GND	50	GND
16	UIM_VPP	35	GND	51	Reserved
17	UIM_C8/Reserved			52	+3.3V
18	GND				
19	UIM_C4/Reserved				




Board Top




MC2

Description: PCIe MiniCard socket
Connector Type: Onboard 0.8mm pitch 52-pin edge card connector

Pin	Desc.	Pin	Desc.	Pin	Desc.
1	Wake	20	W_Disable#	36	USB D-
2	+3.3V	21	GND	37	GND
3	COEX1	22	PERST#	38	USB D+
4	GND	23	PERn0	39	+3.3V
5	COEX2	24	+3.3V	40	GND
6	+1.5V	25	PERp0	41	+3.3V
7	CLKREQ#	26	GND	42	LED WWAN#
8	UIM_PWR	27	GND	43	GND
9	GND	28	+1.5V	44	LED_WLAN#
10	UIM_DATA	29	GND	45	Reserved
11	REFCLK-	30	SMB_CLK	46	LED_WPAN#
12	UIM_CLK	31	PETn0	47	Reserved
13	REFCLK+	32	SMB_DATA	48	+1.5V
14	UIM_RESET	33	PETp0	49	Reserved
15	GND	34	GND	50	GND
16	UIM_VPP	35	GND	51	Reserved
17	UIM_C8/Reserved			52	+3.3V
18	GND				
19	UIM_C4/Reserved				




Board Top




DIO1

Description: Digital I/O connector
Connector Type: 25-pin female DB connector




Pin	Desc.	Pin	Desc.
1	DIO0	14	DIO1
2	DIO2	15	DIO3
3	DIO4	16	DIO5
4	DIO6	17	DIO7
5	DIO8	18	DIO9
6	DIO10	19	DIO11
7	DIO12	20	DIO13
8	DIO14	21	DIO15
9	+5V	22	GND
10	+5V	23	GND
11	N.C	24	N.C
12	N.C	25	N.C
13	N.C		

Board Top




Rear Panel



PWRIN1


Description: DC-in power receptacle
Connector Type: 5.00mm-pitch 4-pole Euro-Type terminal block




Pin Desc.

Pin	Desc.
1	PWRINV+
2	PWRINV-
3	C-GND
4	PWR_IN_SW#

Board Top



Rear Panel



DP1A&DP1B


Description: DisplayPort double stack connectors

Connector Type: DisplayPort digital video connector




Pin	Desc.	Pin	Desc.
1	DDIC_TXC0_CON	11	GND
2	GND	12	DDIC_TXC3#_CON
3	DDIC_TXC0#_CON	13	DDPC_DP_AUX_EN#
4	DDIC_TXC1_CON	14	DDPC_DP_CONFIG2
5	GND	15	DDPC_AUXP_CON
6	DDIC_TXC1#_CON	16	GND
7	DDIC_TXC2_CON	17	DDPC_AUXN_CON
8	GND	18	DDPC_HPD_CON
9	DDIC_TXC2#_CON	19	GND
10	DDIC_TXC3_CON	20	PWR

Board Top



Rear Panel




JPIC1


Description: PIC programming pin header

Connector Type: Onboard 2.0mm pitch 6-pin header

Pin	Desc.	Pin	Desc.
1	N/C	2	ICSP-CLK
3	ICSP-DAT	4	GND
5	VCC5_PIC	6	MCU_RST




Board Top



LAN2&LAN3


Description: One Ethernet port over double-stacked USB 3.0 ports

Connector Type: One 8P8C RJ45 connector w/ two SuperSpeed type-A USB 3.0 connectors




LAN (RJ-45)				USB (Type-A)	
Pin	Desc.	Pin	Desc.	Pin	Desc.
1	MDI0+	5	MDI2+	1	VBUS
2	MDI0-	6	MDI2-	2	Data-
3	MDI1+	7	MDI3+	3	Data+
4	MDI1-	8	MDI3-	4	GND
				5	StdA_SSRX-
				6	StdA_SSRX+
				7	GND_DRAIN
				8	StdA_SSTX-
				9	StdA_SSTX+

Board Top




Rear Panel



USB1 and USB4


Description: Connectors for the internal USB ports (for FPC-7601/7602/7603 only, Configure-to-Order)

Connector Type: 1 x 5-pin wafer connector



USB1		USB4	
Pin	Desc.	Pin	Desc.
1	+5V	1	+5V
2	D-	2	D-
3	D+	3	D+
4	GND	4	GND
5	GND	5	GND

Board Bottom




Engine of the Computer

COM1&COM2

Description: Serial port 1&2, RS232 ports

Connector Type: 9-pin male DB connector


Pin Definition:




RS232

Pin	Desc.	Pin	Desc.
1	DCD	2	RXD
3	TXD	4	DTR
5	GND	6	DSR
7	RTS	8	CTS
9	RI	10	N.C

Board Top




Rear Panel



COM3&COM4

Description: Serial port 3&4, configurable between RS232, RS422 and RS485.

Connector Type: 9-pin male DB connector




Pin Definition:

RS232				RS485		RS422	
Pin	Desc.	Pin	Desc.	Pin	Desc.	Pin	Desc.
1	DCD	6	DSR	1	RS485D-	1	RS422 TX-
2	RXD	7	RTS	2	RS485D+	2	RS422 TX+
3	TXD	8	CTS	5	GND	3	RS422 RX+
4	DTR	9	RI			4	RS422 RX-
5	GND					5	GND


To switch between RS232/422/485 mode, refer to BIOS setting: [5.2.7. F81866 Super IO Configuration](#)

To switch the RS485/422 terminal mode, refer to P.21 JTERM1/2 setting.

Board Top



Rear Panel



This page is intentionally left blank.

Chapter 4

Installation and Maintenance

4.1. Install Hardware

The FPC-7600 Series is constructed based on modular design to make it easy for users to add hardware or to maintain the computer. The following sections will guide you to the simple hardware installations for the computer.


4.1.1. Open the Computer

For the computer, removing the top and bottom covers is essential to open the computer and access the inside. Follow through the steps below to remove the top cover and bottom cover from the computer.

4.1.1.1. Remove Top Cover

All jumpers, MiniCard socket, SDRAM SO-DIMM slots, DIO port and PIO port (printer port) are built on the top side of the main board. To access these components, the computer's top cover has to go. Follow through the steps below to remove the top cover.

1. Place the computer on a flat surface. Loosen and remove those screws as marked in the illustration below.



After the said screws are removed, proceed to dismount the top cover. Carefully lift the top cover and then completely part the top cover from the computer.



The inside of the computer comes to view.

FPC-7600



FPC-7601~04




- ▶ To adjust jumpers or connect/disconnect cables to/from the main board, see [3.2. Jumpers and Connectors](#) on page [22](#).
- ▶ To install memory modules, see [4.1.2. Install/uninstall Memory Modules](#) on page [44](#).
- ▶ To install MiniCard-based wireless modules, see [4.1.6. Install Wireless Modules](#) on page [58](#).

4.1.1.2. Remove the Bottom Cover

The Serial ATA connectors, the power connectors for SATA storage devices, and the internal USB ports (configure-to-order for FPC-7601/7602/7603 only), PCI and PCIe connectors are all built on the bottom side of the main board. To access these connectors, the computer's bottom cover has to go. Follow through the steps below to remove the bottom cover from the computer.

1. Place the computer upside down on a flat surface. Loosen and remove the 2 screws as marked in the illustration below.



2. After the said screws are removed, proceed to dismount the bottom cover. Carefully lift and then completely part the bottom cover from the computer.

FPC-7600




FPC-7601~04




The inside of the computer comes to view.

FPC-7600




FPC-7601~04



- ▶ To install internal USB drives, see [4.1.3. Install CPU](#) on page [52](#).
- ▶ To install SATA storage devices, see [4.1.4. Install SATA Storage Devices](#) on page [53](#).
- ▶ To install PCI/PCIe cards, see [4.1.5. Install PCI and PCI Express Cards](#) on page [56](#).


4.1.2. Install/uninstall Memory Modules

The main board has two dual inline memory module (DIMM) sockets. Increase memory capacity to make programs run faster on the system. The memory module for the FPC-7600 Series' SO-DIMM sockets should be a 204-pin DDR3 with a “key notch” off the centre among the pins, which enables the memory module for particular applications. There are another two notches at each left and right side of the memory module to help fix the module in the socket.




To install a DDR3 memory module:

1. Remove the top cover from the computer as described in [4.1.1.1. Remove Top Cover](#) on page [40](#).
2. Find the SO-DIMM sockets on the board as marked in the illustration below.




The SO-DIMM sockets are vertical type, and each socket has two latches for fixing the memory modules. The memory module can only be installed by one direction due to the notch.

3. Pull back both latches from the socket.



vertical-type SO-DIMM socket (overview)

4. Confront the memory module's edge connector side at the SO-DIMM socket. Position the memory module at the SO-DIMM socket, with the memory module's key notch aligned at the break of the SO-DIMM's slot connector.
5. Vertically plug the memory module to the DIMM socket. "Fully" plug the memory module until both latches auto-lock the memory module in place.




6. Restore the top cover to the computer.

To uninstall a DDR3 memory module:

1. Pull back both latches from the SO-DIMM socket.
The DDR3 memory module will be auto-released from the socket.
2. Remove the memory module.
3. Restore the top cover to the computer.


Install Memory Module with Heat Spreaders

1. Have the heat spreaders. One has the bigger fin and the other has the smaller fin.




Each heat spreader comes with a thermal pad.

2. Attach the memory module to the thermal pad side of the heat spreader with bigger fin. See the picture below.





Attach the memory module to the thermal pad

The connector break on the 204-pin memory module






View from the other side..

3. Attach the other heat spreader to the other side of the memory module so the two heat spreaders sandwich the memory module. Be sure to align the two heat spreaders properly so as to form the two clip holes.




Installation & Maintenance




4. Have the two metal clips. Use them to hold the heat spreaders and the memory module together.



Make sure the heat spreaders are clipped exactly as shown in the pictures below.



5. Fully push the clips until they cannot be pushed any more. See the pictures below.



Installation & Maintenance


Note: The above mentioned demonstrated one clip only. When you install the memory module with heat spreaders, be sure to use both clips.

6. Remove the top cover from the computer as described in [4.1.1.1. Remove Top Cover](#) on page 40.
7. Find the SO-DIMM sockets on the board as marked in the illustration below.



The SO-DIMM sockets are vertical type, and each socket has two latches to fix the memory modules. The memory module can only be installed by one direction due to the key notch.


8. Pull back both latches from the socket.




vertical-type SO-DIMM socket (overview)

9. Confront the memory module's edge connector side at the SO-DIMM socket. Position the memory module at the SO-DIMM socket, with the memory module's key notch aligned at the break of the SO-DIMM's slot connector.

10. Vertically plug the memory module to the DIMM socket. “Fully” plug the memory module until both latches auto-lock the memory module in place.




11. Attach another thermal pad onto the top of the heat spreaders.




12. Restore the top cover to the computer.

4.1.3. Install CPU

1. Locate the six screws which secure the Thermal Lump.
2. Use a screwdriver to remove the six screws and keep them safely for later use.



3. The processor socket comes with a screw to secure the CPU. As shown in the picture below, loose the screw first before inserting the CPU.



4. Place the CPU into the socket by making sure the notch on the corner of the CPU corresponding with the notch on the inside of the socket. Once the CPU is slid into the socket, lock the screw.


5. The contact area and gap between the processor and the heatsink require a thermal pad or thermal paste. Make sure that heatsink of the CPU top surface is in complete contact to avoid the CPU overheating problem. If not, it would cause your system or CPU to be hanged, unstable, or damaged.

4.1.4. Install SATA Storage Devices


The computer supports two 2.5" SATA storage devices to work inside the computer for RAID. The following will guide you to install two SATA HDD or SSD.

4.1.4.1. Install SATA Storage Devices for FPC-7600 Series

1. Remove the bottom cover from the computer as described in [4.1.1.2. Remove the Bottom Cover](#) on page 42..
2. Find the HDD/SSD brackets inside the computer. Loosen and remove the screws as marked in the illustration below. Then dismount the brackets from the computer.



FPC-7600



FPC-7601~04

Installation & Maintenance

3. For the 1st storage bracket: Slide an HDD/SSD storage device into the bracket.



FPC-7600



FPC-7601~04

4. Fix the storage device in place by using screws at the four screw holes on both sides of the bracket.




FPC-7600




FPC-7601~04

5. Install the bracket and the storage device back into the computer by refastening the four screws.




FPC-7600




FPC-7601~04

6. Connect the SATA signal cable(s) and power cable(s).



FPC-7600



FPC-7601~04

7. Restore the bottom cover to the computer.

4.1.5. Install PCI and PCI Express Cards


The FPC-7600 series supports PCIe x16 slots, PCIe x8 slots, and PCI slots. Different SKUs have different options, please refer to [Section 1.5. Ordering Information on page 5](#). Follow the guide below to install an PCI Express or PCI card to the computer.

To install a PCI or PCI Express card:


1. Remove the bottom cover from the computer as described in [4.1.1.2. Remove the Bottom Cover](#) on page 42.
2. Use a cross head screwdriver to loose the screw that secure the expansion slot bracket. And then you can install a PCIe card to this expansion slot.



3. If you want to install the PCIe card to the lower slot, please push the rubber cover out of the unit.



-
4. Use the screwdriver to loose the screw securing the lower expansion slot bracket.



4.1.6. Install Wireless Modules

The computer comes with two **Mini-card** sockets to load the computer with the wireless modules of **PCI Express Mini-card** form factor. The configure-to-order wireless modules available with the computer is the Wi-Fi module **WIFI-AT2300**:



WIFI-AT2300
Atheros AR9462 Wi-Fi module w/ 20cm internal wiring


(See also [1.5.2. Configure-to-Order Service](#) on page 6.)

- If you have ordered the Wi-Fi module **WIFI-AT2300**, see Appendix on [C: Wi-Fi Module WIFI-AT2300 Hardware Installation](#) page [96](#) to know how to install the hardware and software for the module.

4.2. Mount the Computer

Integrate the computer to where it works by mounting it to a wall in the surroundings. Such integration relies on a wall-mount kit, which is available on option. Follow through the guide below to assemble the kit to the computer:

1. Place the computer upside down on a flat surface. Find the eight screw holes at its bottom as marked in the red circles in the illustration below:




2. Have the two wall-mount brackets. Use the screws included in the wall-mount kit to assemble each of the brackets to the computer's bottom by the screw holes on them (as marked in the blue circles in the illustration above).
3. Use the other screw holes and cutouts on both wall-mount brackets to mount the computer to a wall. (See the green circles in the illustration below).



4.3. Ground the Computer

Follow the instructions below to ground the computer to land. Be sure to follow every grounding requirement in your place.

 **Warning** Whenever the unit is installed, the ground connection must always be made first of all and disconnected lastly.

1. See the illustration below. Remove the ground screw from the rear panel.
2. Attach a ground wire to the rear panel with the screw.



FPC-7600



FPC-7601~03



FPC-7604


4.4. Wire DC-in Power Source



Warning Only trained and qualified personnel are allowed to install or replace this equipment.

Follow the instructions below for connecting the computer to a DC-input power source.

1. Before wiring, make sure the power source is disconnected.
2. Find the terminal block in the accessory box.
3. Use the wire-stripping tool to strip a short insulation segment from the output wires of the DC power source.
4. Identify the positive and negative feed positions for the terminal block connection. See the symbols printed on the rear panel indicating the polarities and DC-input power range in voltage.
5. Insert the exposed wires into the terminal block plugs. Only wires with insulation should extend from the terminal block plugs. Note that the polarities between the wires and the terminal block plugs must be positive to positive and negative to negative.
6. Use a slotted screwdriver to tighten the captive screws. Plug the terminal block firmly, which wired, into the receptacle on the rear panel.



This page is intentionally left blank.


Chapter 5

BIOS

BIOS

The BIOS Setup utility for the FPC-7600 Series is featured by American Megatrends Inc to configure the system settings stored in the system's BIOS ROM. The BIOS is activated once the computer powers on. When the computer is off, the battery on the main board supplies power to BIOS RAM.

To enter the BIOS Setup utility, keep hitting the “Delete” key upon powering on the computer.



The featured settings are:

Menu	Description
Main	See 5.1. Main on page 66 .
Advanced	See 5.2. Advanced on page 67 .
Chipset	See 5.3. Chipset on page 78 .
Boot	See 5.4. Boot on page 85 .
Security	See 5.5. Security on page 88 .
Save & Exit	See 5.6. Save & Exit on page 89 .

Key Commands

The BIOS Setup utility relies on a keyboard to receive user's instructions. Hit the following keys to navigate within the utility and use the utility.

Keystroke	Function
← →	Moves left/right between the top menus.
↓ ↑	Moves up/down between highlight items.
Enter	Selects an highlighted item/field.
Esc	<ul style="list-style-type: none"> ▶ On the top menus: Use Esc to quit the utility without saving changes to CMOS. (The screen will prompt a message asking you to select OK or Cancel to exit discarding changes. ▶ On the submenus: Use Esc to quit current screen and return to the top menu.
Page Up / +	Increases current value to the next higher value or switches between available options.
Page Down / -	Decreases current value to the next lower value or switches between available options.
F1	Opens the Help of the BIOS Setup utility.
F10	Exits the utility saving the changes that have been made. (The screen then prompts a message asking you to select OK or Cancel to exit saving changes.)

Note: Pay attention to the "WARNING" that shows at the left pane onscreen when making any change to the BIOS settings.

This BIOS Setup utility is updated from time to time to improve system performance and hence the screenshots hereinafter may not fully comply with what you actually have onscreen.

BIOS

5.1. Main

The **Main** menu features the settings of **System Date** and **System Time** and displays some BIOS info.

The BIOS info displayed are:


Info	Description
BIOS Vendor	Delivers the provider of the BIOS Setup utility.
Core Version	Delivers the version info of the core.
Compliancy	Delivers the UEFI support.
Project Version	Delivers the computer's BIOS version.
Build Date and Time	Delivers the date and time when the BIOS Setup utility was made/updated.
Access Level	Delivers the level that the BIOS is being accessed at the moment.

The featured settings are:

Setting	Description
Language	The system language is set to English and cannot be changed.
System Time	Sets system time.
System Date	Sets system date.

5.2. Advanced

Access the **Advanced** menu to manage the computer's system configuration including the Super IO chip, Fintek 81866.



The featured settings and submenus are:

Setting	Description
ACPI Settings	See 5.2.1. ACPI Settings on page 68 .
SS RTC Wake Settings	See 5.2.2. SS RTC Wake Settings on page 69 .
CPU Configuration	See 5.2.3. CPU Configuration on page 70 .
SATA Configuration	See 5.2.4. SATA Configuration on page 71 .
Intel Anti-Theft Technology Configuration	See 5.2.5. Intel(R) Anti-Theft Technology Configuration on page 72 .
USB Configuration	See 5.2.6. USB Configuration on page 73 .
F81866 Super IO Configuration	See 5.2.7. F81866 Super IO Configuration on page 74 .
F81866 H/W Monitor	See 5.2.8. F81866 H/W Monitor on page 76 .
Intel ICC	See 5.2.9. Intel ICC on page 77 .
CPU PPM Configuration	See 5.2.10. CPU PPM Configuration on page 78 .

BIOS

5.2.1. ACPI Settings

The submenu **ACPI Settings** enable users to change the system's ACPI (Advanced Configuration and Power Interface) configuration by the following settings:

Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc.

Main **Advanced** Chipset Boot Security Save & Exit


<p>ACPI Settings</p> <p>Enable Hibernation [Enabled]</p> <p>ACPI Sleep State [S1 only(CPU Stop C1...)]</p> <p>Power-supply Type [ATX]</p>	<p>Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may be not effective with some OS.</p>
<p>←→: Select Screen ↓ ↑: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit</p>	

Version 2.17.1247. Copyright (C) 2015 American Megatrends, Inc.

Setting	Description
Enable Hibernation	<p>Enables/disables the system to/from hibernation (OS/S4 Sleep State).</p> <ul style="list-style-type: none"> ▶ This option may not be effective with some OS. ▶ Options available are Enabled (default) and Disabled.
ACPI Sleep State	<p>Sets the ACPI sleep state for the system to enter when the suspend button is hit.</p> <ul style="list-style-type: none"> ▶ Options available are Suspend Disabled, S1 only (CPU Stop Clock), S3 only (Suspend to RAM) and Both S1 and S3 available for OS to choose from. ▶ S3 only (Suspend to RAM) is the default.
Power-Supply Type	<p>Configures system power-supply type.</p> <ul style="list-style-type: none"> ▶ Options available are AT, and ATX (default).

5.2.2. SS RTC Wake Settings

Access this submenu to configure whether and when to awake the system.



The featured settings are:

Setting	Description								
Wake System with Fixed Time	Sets if to awake the system at a defined moment. <ul style="list-style-type: none"> ▶ Options available are Enabled and Disabled (default). ▶ Enable this feature to awake the system at a defined moment in time. When enabled, the following settings become available: 								
	<table border="1"> <thead> <tr> <th>Setting</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Wake up hour</td> <td>Defines the (hour) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 23 configurable. </td> </tr> <tr> <td>Wake up minute</td> <td>Defines the (minute) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 59 configurable. </td> </tr> <tr> <td>Wake up second</td> <td>Defines the (second) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 59 configurable. </td> </tr> </tbody> </table>	Setting	Description	Wake up hour	Defines the (hour) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 23 configurable. 	Wake up minute	Defines the (minute) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 59 configurable. 	Wake up second	Defines the (second) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 59 configurable.
	Setting	Description							
	Wake up hour	Defines the (hour) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 23 configurable. 							
Wake up minute	Defines the (minute) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 59 configurable. 								
Wake up second	Defines the (second) time to awake the system. <ul style="list-style-type: none"> ▶ 0 to 59 configurable. 								

BIOS

Wake System with Dynamic Tlme	Sets if to awake the system some time in the future.	
	<ul style="list-style-type: none"> ▶ Options available are Enabled and Disabled (default). ▶ Enable this feature to awake the system some time from now. When enabled, the following setting becomes available: 	
	Setting	Description

Wake up minute increase	Defines how long from now to awake the system. <ul style="list-style-type: none"> ▶ 1 to 5 minutes configurable.
--------------------------------	---

5.2.3. CPU Configuration

Select **CPU Configuration** to run a report of the CPU's details including: model name, processor speed, microcode revision, max./min. processor speeds, the amount of processor core(s), and CPU caches. See the depiction below:

Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc.	
Main Advanced Chipset Boot Security Save & Exit	

CPU Configuration Intel(R) Core(TM) i5-3610ME CPU @ 2.70GHz CPU Signature 306a9 Microcode Patch 10 Max CPU Speed 2700 MHz Min CPU Speed 1200 MHz CPU Speed 2700 MHz Processor Cores 2 Intel HT Technology Supported Intel VT-x Technology Supported Intel SMX Technology Supported 64-bit Supported L1 Data Cache 32 kB x 2 L1 Code Cache 32 kB x 2 L2 Cache 256 kB x 2 L3 Cache 3072 kB Intel Virtualization Technology [Enabled]	Enable/Disale Intel SpeedStep ←→: Select Screen ↓ ↑: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
--	---

Version 2.14.1247. Copyright (C) 2015 American Megatrends, Inc.

5.2.4. SATA Configuration

SATA Configuration manages the system’s SATA configuration and also delivers its status.

Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc.

Advanced

SATA Controller(s) SATA Mode Selection SATA Controller Speed Serial ATA Port 0 Software Preserve Serial ATA Port 1 Software Preserve Serial ATA Port 2 Software Preserve Serial ATA Port 4 Software Preserve Serial ATA Port 5 Software Preserve	[Enabled] [AHCI] [Gen3] INTEL SSDSC2BB (80.0G Supported) INTEL SSDSC2BB (80.0G Supported) Empty Empty Unknown Empty Unknown Empty Unknown	Enable or disable SATA Device. ⇐+: Select Screen ↓ ↑: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
--	--	--


Version 2.17.1246. Copyright (C) 2015 American Megatrends, Inc.

The featured settings are:

Setting	Description
SATA Controller(s)	Enables/disables SATA device(s). ▶ Enabled is the default.
SATA Mode Selection	Configures how SATA controller(s) operate. ▶ Options available are IDE , AHCI (default) and RAID .
SATA Controller Speed	Configures the maximum speed of SATA controller ▶ Options available are Gen1 , Gen2 and Gen3 (default).
Serial ATA Port 0 ,1 ,2,4,5.	SATA device information

5.2.5. Intel(R) Anti-Theft Technology Configuration


Disabling Intel(R) AT Allow User to login to platform. This is strictly for testing only. This does not disable Intel(R) AT Services in ME.



Setting	Description
Intel(R) Anti-Theft Technology	Enables (default)/disables Intel(R) AT in BIOS.
Intel(R) Anti-Theft Technology Rec	Set the number of times Recovery attempted will be allowed.

5.2.6. USB Configuration

Select this submenu to view the status of the USB devices and configure USB features.




The featured settings are:

Setting	Description
Legacy USB Support	<p>Enables/disables legacy USB support.</p> <ul style="list-style-type: none"> ▶ Options available are Enabled (default), Disabled and Auto. ▶ Select Auto to disable legacy support if no USB device are connected. ▶ Select Disabled to keep USB devices available only for EFI applications.
USB3.0 Support	<p>Enables/disables USB3.0 Support.</p> <p>The optional settings are: Disabled / Enabled.</p>

BIOS

5.2.7. F81866 Super IO Configuration

This submenu configures the Super IO chip (Fintek F81866) for the computer's serial ports 1~4 and the parallel port. The featured submenus are:



Submenu	Description	
Serial Port 1 Configuration	Configures the computer's COM1. The featured settings are:	
	Setting	Description
	Serial Port	Enables/disables the serial port. ▶ Enabled is the default.
	Change Settings	Select an optimal setting for Super IO device.
Serial Port 2 Configuration	Configures the computer's COM2. The featured settings are:	
	Setting	Description
	Serial Port	Enables/disables the serial port. ▶ Enabled is the default.
	Change Settings	Select an optimal setting for Super IO device.

Serial Port 3 Configuration	Configures the computer's COM3 , which is fixed to RS232 and cannot be changed. The featured settings are:	
	Setting	Description
	Serial Port	Enables/disables the serial port. ▶ Enabled is the default.
	Change Settings	Select an optimal setting for Super IO device.
Serial Port 4 Configuration	Serial Port 1	Select RS232 , RS422 , and RS485 mode ▶ RS232 is the default.
	Configures the computer's COM4, which is fixed to RS232 and cannot be changed. The featured settings are:	
	Setting	Description
	Serial Port	Enables/disables the serial port. ▶ Enabled is the default.
Change Settings	Select an optimal setting for Super IO device.	
Serial Port 1	Select RS232 , RS422 , and RS485 mode ▶ RS232 is the default.	
Power On After Power Fail	Sets whether the system should power on or power off when the power supply resumes after an power failure. ▶ Options are Power off (default) and Power on .	

BIOS

5.2.8. F81866 H/W Monitor

Select this submenu to view the main board's hardware status. Select it to run a report of various info as depicted below:

The screenshot shows the Aptio Setup Utility interface. At the top, it says "Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc." Below this is a navigation bar with tabs: "Main", "Advanced", "Chipset", "Boot", "Security", and "Save & Exit". The "Advanced" tab is selected. The main area is titled "PC Health Status" and displays the following hardware information:

CPU temperature	: +50 °C
System temperature	: +53 °C
VCORE	: +1.748 V
5VSB	: +5.087 V
+5V	: +4.945 V
+12V	: +12.320 V


Below the hardware information, there is a legend for navigation keys:

- ←: Select Screen
- ↓↑: Select Item
- Enter: Select
- +/-: Change Opt.
- F1: General Help
- F2: Previous Values
- F9: Optimized Defaults
- F10: Save & Exit
- ESC: Exit

At the bottom of the screen, it says "Version 2.17.1247. Copyright (C) 2015 American Megatrends, Inc."

5.2.9. Intel ICC


Select this submenu to configure the serial port console redirection configuration.



The featured setting is:

Setting	Description
Use Watchdog Timer for ICC	Enables/Disables Watchdog Timer operation for ICC. ▶ Disabled is the default.
Turn off unused PCI/PCIe clocks	Enables/Disables clocks for empty PCI/PCIe slots to save power. ▶ Enabled is the default.
Lock ICC registers	Configures ICC register Lock. ▶ Options available are All registers , and Static only (default).

5.2.10. CPU PPM Configuration




The featured settings are:

Setting	Description
Turbo Mode	Enables/Disables CPU Turbo Mode. ▶ Enabled is the default.

5.3. Chipset

The **Chipset** menu controls the system’s chipset.



The featured submenus are **PCH-IO Configuration** and **System Agent (SA) Configuration**, which are explicated in the following of this section.


Submenu overview:

Submenu	Description
PCH-IO Configuration	Configures the PCH (Platform Controller Hub). See 5.3.1. PCH-IO Configuration on page 80 for the settings.
System Agent (SA) Configuration	Configures the System Agent (SA), i.e. the north bridge. See 5.3.1.1. USB Configuration on page 81 for the settings.

BIOS

5.3.1. PCH-IO Configuration

Select this submenu to view the RC version, SKU name and revision ID of the Intel® PCH. Select this submenu also to configure the PCH:




The featured settings/submenus are:

Setting /Submenu	Description
USB Configuration	See 5.3.1.1. USB Configuration on page 81 .
PCH LAN Controller	Enables/disables the onboard NIC. ▶ Enabled is the default.
High Precision Timer	Enables/disables the High Precision Timer. ▶ Enabled is the default.
SLP_S4 Assertion Width	Configure the minimum assertion width of the SLP_S4# Signal. ▶ 4-5 Seconds is the default.

5.3.1.1. USB Configuration

Access this submenu to configure the system's USB ports.




The featured settings are:

Setting	Description
EHCI1	Enables/disables the USB EHCI (USB2.0) functions. ▶ Enabled is the default. ▶ One EHCI controller must always be enabled.
EHCI2	Enables/disables the USB EHCI (USB2.0) functions. ▶ Enabled is the default. ▶ One EHCI controller must always be enabled.

5.3.2. System Agent (SA) Configuration

Select this submenu to view the name and RC version of the **System Agent (SA)**, i.e. the north bridge. Select this submenu also to configure the **System Agent (SA)** by the following setting and submenus:



Setting / Submenu	Description
VT-d	Enables/disables Intel® virtualization technology for directed I/O on the MCH (memory controller hub). ▶ Enabled is the default.
Graphics Configuration	See 5.3.2.1. Graphics Configuration on page 83 .
NB PCIe Configuration	See 5.3.2.2. NB PCIe Configuration on page 83 .
Memory Configuration	See 5.3.2.3. Memory Configuration on page 84 .

5.3.2.1. Graphics Configuration

Select **Graphics Configuration** to view graphics info and accesses graphics settings.

The featured settings are:

Setting	Description
IGFX VBIOS Version	Display the IGFX(internal VGA) VBIOS version.
IGFX Frequency	Display the IGFX frequency
Graphics Turbo IMON Current	Sets the graphics turbo IMON current values. <ul style="list-style-type: none"> ▶ Options available are 14 to 31. ▶ 31 is the default.
Primary Display	Select the Graphics device which will be activated as Primary Display. <ul style="list-style-type: none"> ▶ Options available are Auto (Default), IGFX, and PEG.
Internal Graphics	Enables/disables the IGD. <ul style="list-style-type: none"> ▶ Options available are Auto (Default), Disabled, and Enabled.

5.3.2.2. NB PCIe Configuration

Access this submenu to configure the system's PCIe.

Setting	Description
PEG0	Display the PEG0 status.
PEG0-Gen X	Configure the PEG0 <ul style="list-style-type: none"> ▶ Options available are Auto/Gen1/Gen2/Gen3. ▶ Gen3 is the default.
PEG0 ASPM	Configure the PEG0 ASPM <ul style="list-style-type: none"> ▶ Options available are Disabled/Auto/ASPM L0s/ASPM L1/ASPM L0sL1. ▶ Disabled is the default.

BIOS

5.3.2.3. Memory Configuration

Display the memory information

Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc.

Chipset


Memory Information		
Memory RC Version	1.2.0.0	
Memory Frequency	1600 Mhz	
Total Memory	4096 MB (DDR3)	
DIMM#0	4096 MB (DDR3)	
DIMM#2	Not Present	
CAS Latency (tCL)	11	
Minimum delay time		
CAS to RAS (tRCmin)	11	
Row Precharge (tRPmin)	11	
Active to Precharge (tRASmin)	28	

→: Select Screen
↑↓: Select Item
Enter: Select
+/-: Change Opt.
F1: General Help
F2: Previous Values
F9: Optimized Defaults
F10: Save & Exit
ESC: Exit

Version 2.17.1247. Copyright (C) 2015 American Megatrends, Inc.

5.4. Boot

The **Boot** menu configures how to boot up the system such as the configuration of boot device priority.



The featured settings and submenu are:

Setting	Description
Setup Prompt Timeout	Set how long to wait for the prompt to show for entering BIOS Setup. <ul style="list-style-type: none"> ▶ The default setting is 1 (sec). ▶ Set it to 65535 to wait indefinitely.
Bootup NumLock State	Sets whether to enable or disable the keyboard's NumLock state when the system starts up. <ul style="list-style-type: none"> ▶ Options available are On (default) and Off.
Quiet Boot	Sets whether to display the POST (Power-on Self Tests) messages or the system manufacturer's full screen logo during booting. <ul style="list-style-type: none"> ▶ Select Disabled to display the normal POST message, which is the default.

BIOS

Fast Boot	Enables/disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options. ▶ Disabled is the default.
Boot Option Priority	
Boot Option #1	Set the system boot priorities.
Hard Drive BBS Priorities	Set the hard drive BBS priorities.
CSM parameters	Configures whether to launch the UEFI/legacy OpROM, boot options, filters, etc. See the full settings at 5.4.1. CSM Parameters on page 86 .

5.4.1. CSM Parameters

Access this submenu to configure the execution of OpROM, boot options filter and so on.


Aptio Setup Utility - Copyright (C) 2015 American Megatrends, Inc.		
Main Advanced Chipset Boot Security Save & Exit		
Launch CSM	[Enabled]	This option controls if CSM will be launched
Boot option filter	[Legacy only]	
Launch PXE OpROM policy	[Do not launch]	
Launch Storage OpROM policy	[Legacy only]	
Launch Video OpROM policy	[Legacy only]	
Other PCI device ROM policy	[UEFI OpROM]	
		→+: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F9: Optimized Defaults F10: Save & Exit ESC: Exit
Version 2.17.1246. Copyright (C) 2015 American Megatrends, Inc.		

The featured settings are:

Setting	Description
Launch CSM	Enables/disables launching CSM (capability support module), which provides UEFI with the additional functionality to allow loading a traditional OS or using a traditional OpROM. <ul style="list-style-type: none"> ▶ Options available are: Enabled (default) and Disabled.
Boot Option Filter	Defines the devices to boot the system to. <ul style="list-style-type: none"> ▶ Options available are UEFI and Legacy (default), Legacy only and UEFI only. ▶ This setting is only available when Launch CSM is enabled (set to Always).
Launch PXE OpROM policy	Configures whether to launch the UEFI or legacy OpROM of PXE (Preboot eXecution Environment). <ul style="list-style-type: none"> ▶ Options available are Do not launch (default), UEFI only and Legacy only. ▶ This setting is only available when Launch CSM is enabled (set to Always).
Launch Storage OpROM policy	Configures whether to launch the UEFI or legacy OpROM of storage. <ul style="list-style-type: none"> ▶ Options available are Do not launch, UEFI only and Legacy only (default). ▶ This setting is only available when Launch CSM is enabled (set to Always).
Launch Video OpROM policy	Configures whether to launch the UEFI or legacy OpROM of video. <ul style="list-style-type: none"> ▶ Options available are Do not launch, UEFI only and Legacy only (default). ▶ This setting is only available when Launch CSM is enabled (set to Always).
Other PCI device ROM priority	Configures which OpROM to run for the PCI devices other than network, mass storage, or video. <ul style="list-style-type: none"> ▶ Options available are UEFI OpROM and Legacy OpROM (default).

5.6. Save & Exit

The **Save & Exit** menu features a handful of commands to launch actions from the BIOS Setup utility regarding saving changes, quitting the utility and recovering defaults.



The features settings are:

Setting	Description
Save Changes and Reset	Saves the changes and quits the BIOS Setup utility.
Discard Changes and Exit	Quits the BIOS Setup utility without saving the change(s).
Restore Defaults	Restores all settings to defaults. <ul style="list-style-type: none"> ▶ This is a command to launch an action from the BIOS Setup utility.
Boot Override	Boot Override presents a list in context with the boot devices in the system. Select the device to boot up the system regardless of the currently configured boot priority. <ul style="list-style-type: none"> ▶ This is a command to launch an action from the BIOS Setup utility.

This page is intentionally left blank.



Appendices

A: Digital I/O Setting

Digital I/O can read from or write to a line or an entire digital port, which is a collection of lines. This mechanism helps users achieve various applications such as industrial automation, customized circuit, and laboratory testing. Take the source code below that is written in C for the digital I/O application example.

Sample Codes:

```
/*----- Include Header Area -----*/
#include "math.h"
#include "stdio.h"
#include "dos.h"

#define sioIndex          0x4E                                / *
or 0x2E */
#define sioData  0x4F                                       /* or 0x2F
*/

/*----- routing, sub-routing -----*/
void main()
{
    int iData;

    SioGPIOMode(0x00FF);
    delay(2000);

    SioGPIOData(0x0055);
    delay(2000);

    iData = SioGPIOStatus();
    printf(" Input : %2x \n",iData);
    delay(2000);

    SioGPIOData(0x00AA);
    delay(2000);

    iData = SioGPIOStatus();
    printf(" Input : %2x \n",iData);
    delay(2000);
}

void SioGPIOMode(int iMode)
{
    int iTemp;

    outportb(sioIndex,0x87);                               /* Enable
Super I/O */
    outportb(sioIndex,0x87);
```



```

        outportb(sioIndex,0x07);                               /* Select
logic device - GPIO */
        outportb(sioData, 0x06);

        outportb(sioIndex,0x30);                               /* Enable
GPIO */
        outportb(sioData, 0x01);

        iTemp = iMode & 0x00FF;
        outportb(sioIndex,0xA0);                               /* GPIO
50~57 - Output Enable */
        outportb(sioData,iTemp);

        iTemp = (iMode & 0xFF00) >> 8;
        outportb(sioIndex,0x88);                               /* GPIO
80~87 - Output Enable */
        outportb(sioData,iTemp);

        outportb(sioIndex,0xAA);                               /* Disable
Super I/O */
    }

void SioGPIOData(int iData)
{
    int iTemp;

    outportb(sioIndex,0x87);                                   /* Enable
Super I/O */
    outportb(sioIndex,0x87);

    outportb(sioIndex,0x07);                                   /* Select
logic device - GPIO */
    outportb(sioData, 0x06);

    iTemp = iData & 0x00FF;
    outportb(sioIndex,0xA1);                                   /* GPIO
50~57 - Output Data */
    outportb(sioData,iTemp);

    iTemp = (iData & 0xFF00) >> 8;
    outportb(sioIndex,0x89);                                   /* GPIO
80~87 - Output Data */
    outportb(sioData,iTemp);

    outportb(sioIndex,0xAA);                                   /* Disable
Super I/O */
}

int SioGPIOStatus()
{
    int iStatus;
    int iTemp;

```

Appendices

```
        outportb(sioIndex, 0x87);                                /* Enable
Super I/O */
        outportb(sioIndex, 0x87);

        outportb(sioIndex, 0x07);                                /* Select
logic device - GPIO */
        outportb(sioData, 0x06);

        outportb(sioIndex, 0xA2);                                /* GPIO
50~57 - Status */
        iTemp = inportb(sioData);

        outportb(sioIndex, 0x8A);                                /* GPIO
80~07 - Status */
        iStatus = inportb(sioData);

        outportb(sioIndex, 0xAA);                                /* Disable
Super I/O */

        iStatus = (iStatus<<8) + iTemp;

        return iStatus;
}
```

B: Watchdog Timer (WDT) Setting

WDT is widely used for industry application to monitor the activity of CPU. Application software depends on its requirement to trigger WDT with adequate timer setting. Before WDT time out, the functional normal system will reload the WDT. The WDT never time out for a normal system. The WDT will not be reloaded by an abnormal system, then WDT will time out and auto-reset the system to avoid abnormal operation.

This computer supports 255 levels watchdog timer by software programming I/O ports.

Below is an assembly program example to disable and load WDT.

Sample Codes:

```

/*----- Include Header Area -----*/
#include "math.h"
#include "stdio.h"
#include "dos.h"

#define SIO_INDEX      0x4E                /* or index = 0x2E */
#define SIO_DATA      0x4F                /* or data = 0x2F */

/*----- routing, sub-routing -----*/
void main()
{
    outportb(sioIndex, 0x87);              /* SIO - Enable */
    outportb(sioIndex, 0x87);

    outportb(sioIndex, 0x07);              /* LDN - WDT */
    outportb(sioData, 0x07);

    outportb(sioIndex, 0x30);              /* WDT - Enable */
    outportb(sioData, 0x01);

    outportb(sioIndex, 0xFA);              /* WDTOut - Enable */
    outportb(sioData, 0x01);

    outportb(sioIndex, 0xF6);              /* WDT - Timeout
Value */
    outportb(sioData, 0x05);

    outportb(sioIndex, 0xF5);              /* WDT - Configuration
*/
    outportb(sioData, 0x32);

    outportb(sioIndex, 0xAA);              /* SIO - Disable */
}

```


C: Wi-Fi Module WIFI-AT2300 Hardware Installation

To use Wi-Fi, hardware-wise the computer needs a Wi-Fi module installed, and software-wise the computer needs the device driver and an application program. This appendix will guide you to install the Wi-Fi module **WIFI-AT2300**. (To have a copy of the device driver, please contact ARBOR customer service by the contact info described in [Technical Support](#) on page [viii](#).)

C.1. Install WIFI-AT2300


1. Remove the computer's top cover as described in [4.1.1.1. Remove Top Cover](#) on page [40](#).

The inside of the computer comes to view.




2. Find the **Mini-card** socket for wireless modules on the board as the illustration above shows.

The socket has a break among the connector.



3. Prepare the **WIFI-AT2300** Wi-Fi module kit. The module is a half-size module of **PCI Express Mini-card** form factor, with two U.FL connectors, one is "MAIN", and the other is "AUX".



Appendices

4. In order to make the half-size Wi-Fi module compatible with the **Mini-card** socket, extend the WiFi module with a “mini half bracket”. Join them together by using two screws.




Position the WiFi module and the “mini half bracket” exactly as shown.



Join the WiFi module and the “mini half bracket” by using two screws.

5. Plug the Wi-Fi module to the socket's connector by a slanted angle. Fully plug the module, and note the notch on the wireless module should meet the break of the connector.




Fully plug the module.


6. Press down the module and fix the module in place using two screws.



7. Remove the plastic plug from the computer's rear (or front) panel to make an antenna hole. Keep the plastic plug for any possible restoration in the future.




8. Have the RF antenna. The antenna has an SMA connector on one end and an MHF connector on the other.




Appendices

9. Connect the RF antenna's MHF connector to the Wi-Fi module's "MAIN" connector.




Connect the RF antenna's MHF connector to the Wi-Fi module's "MAIN" connector

10. From the other end of the RF antenna, which is an SMA connector, remove the washer and the nut. Save the washer and nut for later use. Note the SMA connector has the form of a threaded bolt, with one flat side.





Remove the nut and washer.




Among the screw thread, there is a flat side.

11. Pull the SMA connector through the above mentioned antenna hole. Note to meet the aforesaid flat side with the antenna hole's flat side.




12. Mount the washer first and then the nut to the SMA connector. Make sure the nut is tightened.



Appendices

13. Restore the computer's top cover.
14. Have an external antenna. Screw and tightly fasten the antenna to the SMA connector.



15. Swivel the antenna to an angle of best signals.




D: Install Internal USB Drives



Since some critical application programs rely on a USB key to run, an USB drive is necessary to store related encrypted keys and digital certificates. The FPC-7601, FPC-7602 and FPC-7603 allow building one USB port inside the chassis to support one USB drive to work therein for reinforced protection against theft or tamper. (Configure-to-Order only)

To install the internal USB drive(s):

1. Remove the bottom cover from the computer as described in [4.1.1.2. Remove the Bottom Cover](#) on page 42.
2. Find the one USB port inside the computer as marked in the picture below.



3. Install an USB drive to one of the internal USB port.



Adjust this iron to make space for the USB drive installed.

4. Restore the bottom cover to the computer.