# ALGIZ RT7

QUICK START GUIDE

handheld

1 WHAT'S IN THE BOX

The pictures shown below may differ from the actual products. To purchase additional or optional products, contact our customer centre.

Algiz RT7 Main Body

Battery Pack

x 9 pcs

Battery Screws

Charging Adaptor

3.5mm Barrel Connector Cable

Micro USB Cable

Headset

Converter Plugs

② YOUR ALGIZ RT7

Barcode Reader

Proximity Sensor

Light Sensor

Receiver

Charging LED indicator

Front Camera

Docking Contact Pins

Touch Screen Display

Primary Mic

Function keys 4pcs

Ports Cover

LED Flash

Rear Camera

Power Key

Kensington Lock

Volume Keys

Speaker

Secondary Mic

Battery

Strap Mounts 4pcs

③ INSERTING/EXTRACTING SIM/MICRO SD CARD

This is how you insert and remove the SIM/ micro SD.

SD Card
Sim1
Sim2

(4) INSERT/REMOVE BATTERY

To insert the battery

1. Place the battery pack on the back as shown.

2. Using the battery screws (M2 X 5mm) fasten them in position.

To remove the battery

1. Power off the device.

2. Open the battery cover by unfastening the screws.

3. Remove the battery pack.

⑤ POWERING ON/OFF

Press the [Power] button on the right side of the device to turn
the Algiz RT7 unit on/off.

Power Button

⑥ BATTERY CHARGING

Charge the unit for 3 hours before using the device for the first
time.

7 I/O COMPARTMENT LAYOUT

Ethernet RJ45

USB A Host

USB micro

3.5mm Audio Jack
(stereo & mic)

DC Jack

Please go to www.handheldgroup.com/knowledgebase to
download more information.

handheld